


CRAFTSMAN 20V MAX CORDLESS JIG SAW



[Click for Instruction Manual](#)

Kit includes:

- Craftsman cordless jig saw
- 4" Wood cutting blade (availability subject to change)
- Hex wrench
- 20V Lithium ion battery and charger

Jig saws allow the user to make intricate curved cuts in wood and other materials.

Unsure if this item is the right tool for the job?

Check out this tutorial!

[Jig Saw Basics \(article and video\)](#)

*This item was generously donated by Whitmore ACE Hardware.

Interested in this item?

WPLD Library of Things

Call **815-476-2834** for more information!